




5 OHM Resistor Replacement Kit Instructions

1. Disconnect wires and remove existing 4 OHM resistor assemblies and bracket from enclosure.
2. Attach 5 OHM resistor assemblies and bracket to enclosure.
3. Attach wires to terminal strip making special attention to the location of wires on terminal strip. The 2 red wire on the top of the terminal strip and the 2 yellow wires in the middle. See photo below.
4. Tighten terminal screws to secure wires.



9270284.fm

Distribué par :



2 rue René Laennec 51500 Taissy France
Fax: 03 26 85 19 08, Tel : 03 26 82 49 29

Email : hvssystem@hvssystem.com
Site web : www.hvssystem.com